

## **ATTENTION!**

The PM-11 Datalogger has a clock battery, which is disconnected with the use of an insulating strip for preventing discharge during transportation and storage.

Before the first use of PM-11 datalogger, you should remove the insulating strip to activate the battery!

### **Instructions:**

1. Unscrew four screws at the front panel of the PM-11 Datalogger and remove the front lid.
2. Locate the insulating strip marked with the red arrow (see the photo on the right )
3. Pull the strip out in along-arrow direction. The battery is now activated.
4. Put the front lid back and fix it with the four screws.

